



Why use machine adapted clamping units?

Designed specifically for your machine

Better performance

Faster tool changes

Use Coromant Capto tools for turning, milling and drilling

Ready-equipped to channel high pressure coolant to the latest in CoroTurn HP cutting heads

Tooling packages and certificates

When you pay for a new machine, make sure it pays you back.

By reducing payback time, you reduce the time it takes for your new machine to start making your business more profitable. Sandvik Coromant offers custom tooling packages and Tooling Certificates to unleash the potential of your investment, right from the start.

Talk to your Sandvik Coromant Productivity Engineer or visit www.payback-calculator.com to learn more about paying off your new machines faster.

To order or for more information, contact your Sandvik Coromant sales representative or authorized distributor, or call 1-800-SANDVIK (1-800-726-3845).

For clamping unit service, call the Coromant Capto Service Center at (704)714-7765. www.sandvik.coromant.com


E-mail: us.coromant@sandvik.com



Nakamura-Tome

Coromant Capto[®] **Machine Adapted Clamping Units**

For Nakamura-Tome CNC lathes



Available for the following machines:

SC250M, SC200L, SC300M

WT-100, WT-150, WTS-150, WT-250II, WT-300, WTW-150, TW-10, TW-20 (12 and 16 stations)


Super NTJX, Super NTM³, Super NTJ, Super NTX, Super NTY³

Your success in focus




Clamping unit configuration

Internal setup





Internal setup




External setup








Single clamping unit is also right handed.



Single clamping unit is also left handed.

Global standard products


Code key for Coromant Capto® machine adapted clamping units



U.S. local products Code key for Coromant Capto[®] machine adapted clamping units

Static holders





	 D _{5m}
n = Coupling s	size

NAK010 - C)5 ₅	5	060	7	YT 9
)6	5	055		DT
4	5		6	8	9
2 Hand of clamping unit/type of unit		3 T	ype of operation	n	
RC = Right LC = Left NC = Neutral DT = Driven Tool			External nternal		
5 Reference dimension		6	Reference dime	ension	
Gauge line in millimeters from reference point to center line of Coromant Capto coupling		refe	uge line in mil erence point t oto coupling		
8 Coolant					
I = Internal coolant (DTH clamping units only) Note: All static Capto clamping units have internal coolant.					
 T = for machine with half index turret (two clamping units in one holder) T = for machines with 'Y' axis (two clamping units in one holder) 			two clamping holder (chang axis)		

C4 - RC E ² ³	- NAK010	- 05	55 060 6	7	YT 9		
Driven tool holders							
C4 - DT I ² ³	- NAK010	- 06 5	55 055 °	8	DT 9		
1 Coupling size $D_{5m} = Coupling size$	2 Hand of clamping unit/type of RC = Right LC = Left NC = Neutral DT = Driven Tool	unit	3 Type of operat E = External I = Internal	ion			
Size: inch: mm: C3 D_{5m} 1.260 32 C4 D_{5m} 1.575 40 C5 D_{5m} 1.969 50 C6 D_{5m} 2.480 63 C8 D_{5m} 3.150 80							
4 Machine model	5 Reference dimension		6 Reference dir	nension			
Example: NAK = Nakamura	Gauge line in millimeters fror reference point to center line Coromant Capto coupling		Gauge line in millimeters from reference point to face of Coromant Capto coupling				
7 Version	8 Coolant						
A = New design M = Modified from original	I = Internal coolant (DTH clam units only Note: All static Capto clampin have internal coolant.)					
9 Configuration							
SS = for subspindle DT = for main spindle and subspindle (two clamping units in one holder)	TT = for machine with half index turret (two clamping units one holder)YT = for machines with 'Y' axis clamping units in one hold	in (two	XT = two clamping units in one holder (change tools with 'X' axis)				

9 Configuration	
subspindle (two clamping units in one holder) YT = fo	irre ne l

Machines

Nakamura SC-250M; WTS-150; WTW-150; TW10 (TW20/16 stations)

Coromant Capto®

Machine adapted clamping units Standard program

OD clamping unit

C4-TR/LE-NA55-DT1)

Static toolholders



C4-TR/LE-NA55A OD clamping unit, both sides C3-R/LCE-NAK010-055060DT1)

C3-R/LCE-NAK010-055060



Face and ID clamping unit C3-R/LCI-NAK010-075020 C4-TR/LI-NA55A

Driven toolholders



OD drill/milling unit C3-DNE-NA55A-E C3-DNE-NA55A-I *



Face drill/milling unit, I_{1,}=65 C3-DNI-NA55A0E C3-DNI-NA55A0I *



Face drill/milling unit, both sides, I1=65 C3-DTI-NAK010-065055DT1)

Suggested collet chuck adapter for Coromant Capto to maximize tool projection



Collet chuck adapter, short C3-391.14-20 036 ER20

Additional short adapters available through Extended Product Offer.

Ordering example:

C3-RCE-NAK010-055060 (right hand unit) C3-LCE-NAK010-055060 (left hand unit)

Products beginning with Cx-TR/L and Cx-DN, see code key page 4 Products beginning with Cx-R/LC, see code key page 5

¹⁾ Units for SC-250M only

Ratio 1:1

* Internal and external coolant supply - Do not run without coolant. Only use filtered coolant fluid (max. particle size = 100μ m) Max. coolant pressure = 1160 PSI (80 bar)

Machines

Nakamura WT150; Super NTM³; Super NTJ; SC-200L; WT250II

Coromant Capto®

Machine adapted clamping units Standard program

Static toolholders



OD clamping unit C3-R/LCE-NAK010-055060 C4-TR/LE-NA55A



OD clamping unit, both sides C3-R/LCE-NAK010-055060DT C4-TR/LE-NA55A-DT



OD clamping unit, double half index C3-R/LCE-NAK010-060060TT



OD clamping unit, double half index, both sides C3-R/LCE-NAK010-060060DTT

Driven toolholders



OD drill/milling unit C3-DNE-NA55A-E C3-DNE-NA55A-I *




Face drill/milling unit, $I_{1,2}=65$ C3-DNI-NA55A-E C3-DNI-NA55A-I *

Suggested collet chuck adapter for Coromant Capto to maximize tool projection



Collet chuck adapter, short ER20

Additional short adapters available through Extended Product Offer.





Face and ID clamping unit C3-R/LCI-NAK010-075020 C4-TR/LI-NA55A



Face and ID clamping unit, double half index C3-R/LCI-NAK010-082020TT



Face and ID clamping unit, double half index, both sides C3-R/LCI-NAK010-082059DTT



Face drill/milling unit, both sides, I1=65 C3-DTI-NAK010-065055DT

Ordering example: C3-RCE-NAK010-055060 (right hand unit) C3-LCE-NAK010-055060 (left hand unit)

Products beginning with Cx-TR/L and Cx-DN, see code key page 4 Products beginning with Cx-R/LC, see code key page 5

Ratio 1:1

* Internal and external coolant supply - Do not run without coolant. Only use filtered coolant fluid (max. particle size = $100 \mu m$) Max. coolant pressure = 1160 PSI (80 bar)

Machines

Nakamura WT300; Super NTX (TW-20, 12 stations)

Coromant Capto®

Machine adapted clamping units Standard program

Face and ID clamping unit, back set

Face and ID clamping unit, both sides

Face drill/milling unit, both sides, I₁=65

C4-DTI-NAK020-065070DT1)

C4-R/LCI-NAK020-090050MDT

C4-TR/LI-NA65A-SS

Machines

Nakamura Super NTJX

Coromant Capto®

Machine adapted clamping units Standard program

Static toolholders



OD clamping unit C3-R/LCE-NAK010-055060 C4-TR/LE-NA55A



OD clamping unit, both sides C3-R/LCE-NAK010-055060DT C4-TR/LE-NA55A-DT

Driven toolholders



OD drill/milling unit C3-DNE-NA55A-E C3-DNE-NA55A-I *



Face drill/milling unit, I_{1z}=75 C3-DTI-NAK010-075050 C3-DTI-NAK010-0750501 *

Suggested collet chuck adapter for Coromant Capto to maximize tool projection



Collet chuck adapter, short C3-391.14-20 036 ER20

Additional short adapters available through Extended Product Offer.

Static toolholders



OD clamping unit C4-TR/LE-NA65A



C4-TR/LE-NA65A-DT

OD clamping unit, both sides



Face and ID clamping unit C4-TR/LI-NA65A

Driven toolholders



OD drill/milling unit C4-DNE-NA65A-E C4-DNE-NA65A-I *



Face drill/milling unit C4-DNI-NA65A-E C4-DNI-NA65A-I *

Suggested collet chuck adapter for Coromant Capto to maximize tool projection

Collet chuck adapter, short



C4-391.14-20 035 ER20 C4-391.14-25 038 ER25

Additional short adapters available through Extended Product Offer.

Ordering example: C4-TRE-NA65A (right hand unit)


C4-TLE-NA65A (left hand unit)

Products beginning with Cx-TR/L and Cx-DN, see code key page 4 Products beginning with Cx-R/LC, see code key page 5

 $^{\scriptscriptstyle 1)}$ Reversable heads

Ratio = 1:1

* Internal and external coolant supply - Do not run without coolant. Only use filtered coolant fluid (max. particle size = $100 \ \mu m$) Max. coolant pressure = $1160 \ PSI \ (80 \ bar)$





Face and ID clamping unit C3-R/LCI-NAK010-085020 C4-R/LCI-NAK010-085015



Face drill/milling unit, both sides, $\rm I_{1z}{=}65$ C3-DTI-NAK010-075055DT

Ordering example: C3-RCE-NAK010-055060 (right hand unit) C3-LCE-NAK010-055060 (left hand unit)

Products beginning with Cx-TR/L and Cx-DN, see code key page 4 Products beginning with Cx-R/LC, see code key page 5


Ratio 1:1

* Internal and external coolant supply - Do not run without coolant. Only use filtered coolant fluid (max. particle size = $100 \ \mu m$) Max. coolant pressure = $1160 \ PSI \ (80 \ bar)$

Machines

Nakamura WT100; Super NTY³, WY-100

Coromant Capto® Machine adapted clamping units Standard program



Static toolholders



OD clamping unit C3-R/LCE-NAK005-047053

OD clamping unit, double half index

C3-R/LCE-NAK005-051053TT



OD clamping unit, both sides C3-R/LCE-NAK005-047053DT



C3-R/LCE-NAK005-051053DTT Face and ID clamping unit C3-R/LCI-NAK005-073034

both sides

OD clamping unit, double half index,

Face and ID clamping unit, double half index C3-R/LCI-NAK005-073034TT

Driven toolholders



OD drill/milling unit C3-DTE-NAK005-000049



Suggested collet chuck adapter for Coromant Capto to maximize tool projection



Collet chuck adapter, short C3-391.14-20 036 ER20

Additional short adapters available through Extended Product Offer.

Ordering example:


C3-RCE-NAK005-047053 (right hand unit) C3-LCE-NAK005-047053 (left hand unit)

Products beginning with Cx-TR/L and Cx-DN, see code key page 4 Products beginning with Cx-R/LC, see code key page 5

Ratio 1:1

* Internal and external coolant supply - Do not run without coolant. Only use filtered coolant fluid (max. particle size = $100 \ \mu m$) Max. coolant pressure = $1160 \ PSI \ (80 \ bar)$

Operating instructions for Coromant Capto driven toolholders



Torque wrench for tool changing

Coupling			Ordering code Torque wrench	Size	Spare parts
size	ft-lbs	Nm		mm	Key adapter
C3	16	22	TW-30-01	5	5680 035-08
C3	26	35	BT-TK-02	8	5680 035-05
C4	37	50	C-TK-01	10	5680 035-06
C5	52	70	C-TK-01	12	5680 035-07
C6	66	90	C-TK-01	12	5680 035-07

To be calibrated according to ISO 6789, accuracy within 4%

For detailed information, see page G119 in the Sandvik Coromant main catalog.

Torque setting and wrench size

	Coromant Capto spindle with sleeve			Solid Coromant Capto spindle				
Capto size		Wrench size	Torque M _A	- Unlock + lock:	\leq	Wrench size	Max Torque M _A	Unlock + lock:
C3	(See	8 mm	35 Nm	Turn hexagon		5 mm	22 Nm	Turn hexagon
C4		8/10 mm	50 Nm	driver around		8 mm	38 Nm	driver around
C5		12 mm	70 Nm	approx. 140°		10 mm	64 Nm	approx. 180°
C6		12 mm	90 Nm			12 mm	90 Nm	