

INDEX

(1) SPECIFICATION AND ACCESSORIES

GENERAL LAYOUT OF LATHE -----	1
BRIEF SPECIFICATION -----	2
MEASUREMENT -----	3
STANDARD ACCESSORIES -----	4
OPTIONAL ACCESSORIES -----	4
FOUNDATION PLAN -----	5

(2) INSTALLATION

CLEANING -----	6
LIFTING -----	6
INSTALLING -----	7
POWER SOURCE WIRING -----	8
LUBRICATION -----	10
CHUCKS AND CHUCK MOUNTING -----	13

(3) OPERATION


STARTING AND STOPPING -----	15
SELECTION OF SPINDLE SPEEDS -----	16
THREADS AND FEEDS -----	17
THREADS AND FEED DATA PLATE -----	18
CARRIAGE AND APRON -----	19
TAIL STOCK -----	20

(4) MAINTENANCE

SLIDE WAYS ATTENTION -----	21
CROSS-SLIDE NUT -----	21
SPINDLE BEARING ADJUSTMENT -----	22
ADJUSTMENT OF OVERLOAD PROTECTION DEVICE -----	22
LATHE ALIGNMENT -----	23

SPECIFICATION AND ACCESSORIES

GENERAL LAYOUT OF LATHE




- | | |
|---------------------------|----------------------------|
| 1. Electrical box | 9. Apron |
| 2. Spindle | 10. Stand—middle |
| 3. Topslide | 11. Footbrake |
| 4. Saddle and cross—slide | 12. Stand, head—end |
| 5. Bedway | 13. Gear box |
| 6. Tailstock | 14. End cover (gear train) |
| 7. Stand, tail—end | 15. Headstock |
| 8. Lead screw | |

SPECIFICATION AND ACCESSORIES

BRIEF SPECIFICATION						
MODEL	2480	24120	24160	3080	30120	30160
NOMINAL SIZE						
Swing over bed	610mm 24in			760mm 30in		
Swing over cross slide	350mm 13-3/4in			500mm 19-3/4in		
Height of center	305mm 12in			380mm 15in		
Distance between centers	2033 80"	3050 120"	4050 160"	2033 80"	3050 120"	4050 160"
BED						
Width of bedways	485mm 19in					
Total length of bed	3320 130"	4380 172"	5470 215"	3320 130"	4380 172"	5470 215"
Gap type	Swing over gap	820mm 32-1/4in			970mm 38-1/4in	
	Length of gap	515mm 20-1/4in				
	Width in front of face plate	340mm 13-3/8in				
SPINDLE						
Spindle nose mounting	D1-11 CAMLOCK					
Spindle bore	105mm. 4-1/8"					
Taper of spindle bore	M.T.#5 (with center sleeve)					
Number of spindle speeds	18 steps (Forward & Reverse by magnetic clutch control)					
Range of spindle speeds	10-1200 R.P.M. (With Magnetic brake)					
TOOL SLIDE						
Total travel of cross slide	375mm 14-3/4in					
Total travel of top slide	225mm 9in					
Max. size cutting tool	28mm 1-1/8in					
TAIL STOCK						
Total travel of barrel	195mm 6-5/8in					
Taper in barrel	M.T.#5					
Diameter of barrel	80mm 3-1/8in					
THREADS						
Lead screw diameter & pitch	Dia. 38mm. Pitch 12mm. 2 T.P.I.					
Number of Inch threads	60					
Range of Inch threads	1/4-84 TPI					
Number of Metric pitches	60					
Range of Metric pitches	0.2-112 mm					
Number of Diametral pitches	55					
Range of Diametral pitches	1-240 D.P.					
Number of Module pitches	55					
Range of Module pitches	0.05-28 M.P.					
FEEDS						
Feed rod diameter	38mm 1-1/2in					
Number of feed change	40					
Range of longitudinal feeds	0.040-5.000 in/rev		0.0015-0.2 in/rev			
Range of cross feeds	0.015-4.000 in/rev		0.0006-0.16 in/rev			
MOTOR						
Main spindle motor	15 HP. 11kw					
Coolant pump motor	1/8HP 0.1kw					
Machine net weight	3500kgs.	4000kgs.	4500kgs.	3800kgs.	4300kgs.	4800kgs.
We reserve the right to modify and improve our products.						

SPECIFICATION AND ACCESSORIES



MODEL	A	B	C	D	E
2480	1840mm 73in	3330mm 131in	3570mm 140in	1500mm 59in	1135mm 45in
24120	3050mm 120in	4550mm 179in	4790mm 188in	1500mm 59in	1135mm 45in
24160	4050mm 160in	5560mm 219in	5790mm 228in	1500mm 59in	1135mm 45in
3080	1840mm 73in	3330mm 131in	3570mm 140in	1575mm 62in	1210mm 48in
30120	3050mm 120in	4550mm 179in	4790mm 188in	1575mm 62in	1210mm 48in
30160	4050mm 160in	5560mm 219in	5790mm 228in	1575mm 62in	1210mm 48in

SPECIFICATION AND ACCESSORIES

STANDARD ACCESSORIES:


- Face plate
- Steady rest
- Coolant pump
- 4-way rapid carriage traverse
- Carriage splash guard
- Longitudinal carriage stops
- Chip pans
- Tool kit

OPTIONAL ACCESSORIES:

- 3-jaw chuck
- 4-jaw chuck 18"
- Follow rest
- Work light
- American toolpost
- Digital readout
- Tracer attachment


SPECIFICATION AND ACCESSORIES

FOUNDATION PLAN




SPECIFICATION AND ACCESSORIES

FOUNDATION PLAN



SPECIFICATION AND ACCESSORIES



INSTALLATION

CLEANING

Before operation any controls, remove the anticorrosion coating from all slideways, and the endgear train, using white spirit or Kerosene.

DO NOT USE CELLULOSE SOLVENTS FOR CLEANING AS THEY WILL DAMAGE THE PAINT FINISH.

Oil all bright machined surfaces immediately after cleaning using machine oil or slideway lubricant, use heavy oil or grease on the endgear.

LIFTING


Move and lift the machine by using a 40mm(1-1/2") Diameter and 890mm(35")Long iron bar. Go through the hole of Bed and lift unpacking machine with a wire rope, which have enough capacity against gross weight of this machine.

Raising and lowering the machine should be careful. Do not touch the leadscrew, feedroad spindle or other handwheel.

Be careful not to bump the machinery against the floor.

In order to have the machinery properly balanced before hoisting, it is advisable to move Tailstock and Carriage to the extreme right-hand position; clamp both assemblies firmly in place so they will not accidentally slide to left when lifting.

IMPORTANT: DO NOT USE SLINGS AROUND OUTSIDE OF BED AS LEADSCREW AND FEEDSHAFT MAY BE BENT.





INSTALLATION

INSTALLING

Located the machine on a solid foundation, allowing sufficient area all round for easy working and maintenance (see Foundation plan). The lathe may be used free-standing or bolted to the foundation.

Free-standing: Position lathe on foundation and adjust each of the ten mounting feet to take equal share of the load. Then using an engineers precision level on the bedways adjust the feet to level up machine. Periodically check bed level to ensure continued lathe accuracy.

Fixed installation: Position lathe over six bolts (20 mm. diam.) set into the foundation to correspond with holes in the mounting feet. Accurately level the machine, then tighten hold-down blots. Re-check bed level.




INSTALLATION

POWER SOURCE WIRING (PART 1)

Be sure to protect carefully the electrical wires exposed outside of the machine, which will be liable to be damaged by chips. This will induce a layer-short accident and will lower an efficiency to a considerable extent. The respective wirings should be connected with terminals R,S,T, at the control housing. Which located at the rear side of the front leg. NOTE: This machine is equipped with 8 or 11 kw (10 or 15 HP) main motor. if an electric wire is used a cap-tired code, use size over AWG #12.

After wiring, check the spindle rotating direction. Turn on the power source switch (on the front of electrical box), and main motor push button (on the front of headstock), then turn the start rod (starting lever on the right side of apron) upward, if it forward revolution, it is the correct wiring. if not, replace two of the three wires (R,S,T) Then check the rotation again.


If the spindle speed drops to zero during normal operation, but the pilot light is still on, it indicates that the overload thermal relay is working. Please turn off the main switch, reset the thermal overload relay and restart the machine.



INSTALLATION

LUBRICATION

It is most important to lubricated lathe before operating!
 The operator should be responsible for the proper lubrication of the lathe. The grade and quality of lubricants are given on the following OIL LUBRICATION CHART. The instructions on this chart are essential to the proper oiling of the internal of the lathe. Oil levels should be strictly observed, for it is of primary importance for proper operation and long life that the oil bath for the headstock feed gearbox and apron which always be completely filled. To keep the machine properly lubricated, follow the instructions given on the below chart.




No.	LUBRICATION POINT	VISCOSITY S.U.S. 100F	OIL RECOMMENDED	OIL EXCHANGE / OR REPLENISHMENT
1	Headstock	160	SHELL(TELLUS)25	Three time a year
2	Feed gearbox	320	SHELL(TONNA)33	Three time a year
3	Apron	320	SHELL(TONNA)33	Keep the oil up to the oil window
4	Cross slide screw	320	SHELL(TONNA)33	Once a day
5	Compound slide	320	SHELL(TONNA)33	Once a day
6	Tailstock	320	SHELL(TONNA)33	Once a day
7	Bedways	320	SHELL(TONNA)33	Once a day
8	Leadscrew	320	SHELL(TONNA)33	Once a day
9	Feed rod	320	SHELL(TONNA)33	Once a day
10	Bracket	320	SHELL(TONNA)33	Once a day
11	Change gears	320	SHELL(TONNA)33	Once a day

INSTALLATION

LUBRICATION


There is a oil lubricate cock on the apron side.
 When set the arrow direction at A, it will lubricat Apron, and set the
 arrow direction at S, it will lubricat Saddle cross slide and bedway.
 Nomally set the lever at A.




Oil lubricate cock

Apron


Oil lubricat
to Saddle




Oil lubricat
to Apron




Turn off
oil lubricat




Oil lubricat
1/2 to Apron
and 1/2 to Saddle



Oil lubricat
1/2 to Apron
and 1/2 return
to oil reservoir



Oil lubricat
1/2 to Saddle
and 1/2 return to
oil reservoir




INSTALLATION

LUBRICATION (Part 3)

In addition to pump-fed lubrication, oiler points are provided for for the saddle, cross-slide, cross-slide nut and using a standard pump-type can with light machine oil or way lubricant.

On the tailstock, tail end of leadscrew oiler points are provide for daily attention from a standard oil can.

It is recommended that all slideways, the leadscrew and feed shaft are cleaned off (a bristle paint brush is useful for this) and lightly oiled after each period of work.



INSTALLATION

CHUCKS AND CHUCK MOUNTING

When mounting chucks or faceplate, first, ensure that spindle and chuck tapers are scrupulously clean and that all cams lock in the correct positions, see Fig. It may be necessary when mounting a new chuck to re-set the camlock studs (A) To do this, remove the cap-head locking screws (B) and set each stud so that the scribed ring (C) is flush with the rear face of the chuck—with the slot lining up with the locking screw hole (see Fig).

Now mount the chuck or faceplate on the spindle nose and tighten the three cams in turn. When fully tightened, the cam lock line on each cam should be between the two V marks on the spindle nose.


If any of the cams do not tighten fully within these limit marks, remove the chuck or faceplate and re-adjust the stud as indicated in the illustration. Fit and tighten the locking screw (B) at each stud before remounting the chuck for work.

This will assist subsequent remounting.


DO NOT INTERCHANGE CHUCKS OR FACEPLATES BETWEEN LATHES WITHOUT CHECKING FOR CORRECT CAM LOCKING BEFOREHAND.

IMPORTANT: Take careful note of speed limitation when using faceplate; 10 inch faceplates should not be run at speeds greater than 1000 rev/min. and 12" faceplate at not more than 770 rev/min.



INSTALLATION



CORRECT



WRONG




OPERATION

STARTING AND STOPPING

Before starting up machine, make sure if the proper lubrication to all running parts has been done as per lubrication chart, and switch on after ensuring the starting levers at feed gear box and apron which should be placed in the neutral position.

First, switch on the Auto. Braker (1) the pilot lamp (2) will be lighted. then push on the main motor control button (3). The starting-up of main spindle is accomplished by the starting lever (4) at the right side of apron. a safety locking device which prevents any abrupt accident from operators. Move this lever horizontally to disengage a safety pin, and move it up or down to get the reverse or forward spindle revolution. When this lever come back to the neutral position, or the foot brake pedals (5) is pressed down, the main spindle will be stopped.

NOTE: The FORWARD-REVERSE revolution is controlled by a Electrol-Magnetic clutch which be fitted inside of headstock. And this clutch cooperates with a Electrol-Magnetic Brake which be fitted left side of headstock to stop the spindle revolving while the main motor is still running. This feature can save the power for motor starting and prolong the life of motor.



OPERATION

SELECTION OF SPINDLE SPEEDS

Select the appropriate spindle speed for working.

There are eighteen steps in the range of spindles (10 - 1200r.p.m) as show on speed chart, divided into three groups.

The change of main spindle speeds are accomplished by the dial level (1) and the lever (2).

Lever (1) selects eighteen grades speeds correspond with lever (2), lever (2) selets HIGH - MIDDLE - LOW position.


Red color position is the HIGH speeds range, 1200 - 215 r.p.m.

Green color position is the MIDDLE speeds range, 150 - 27 r.p.m.

Blue color position is the LOW speeds range, 60 - 10 r.p.m.

Spindle speeds dial (3) shows 18 steps, being divided into 10, 15, 20, 27, 30, 39, 42, 55, 60, 75, 110, 150, 215, 310, 430, 610, 870 and 1200.

In order to obtain the desired spindle speeds. place the lever atthe proper position. Be sure do not shift the levers when the spindle is running.



OPERATION

THREADS AND FEEDS

All the threads and feeds directory available from the gearbox are show on the data plate fitted on the front of the headstock, with the setting of control levers.

Threads and feeds direction can be changed by knob (1) on the headstock, which select Forward or Reverse revolution for Leadscrew and Feed shaft.

Another way, Pull and push the knob (8) on the front of the Apron, which can change the Threads and Feeds direction from the Apron.

The lever (2) on the headstock, which select Fine threads and feeds (for position L); Coarse threads and feeds (for position H)

CAUTION


NOTE: Do not using Coarse threads and feeds (the lever "2" set on position "H") while the spindle speed over 110 r.p.m.

The dial (3) and knob and lever (4), (5), (6) on the gearbox which select all kinds thread and feed as the data plate.

For Feed cutting, the lever (7) should be set on (FEED) position.

For Inch and Metric threading, the lever (7) should be set on (MM, TPI)

For DP and MP threading, the lever (7) should be set on (MP, DP) position.









OPERATION

THREADS AND FEED DATA PLATE

Inch system Leadscrew pitch 2 T.P.I.

Metric system Leadscrew pitch 12 mm.

								
.2 LBES1	1.5 LBDR6	13 LADR7	84 LBCU8	16 LBDV1	3 LADV6	.04 LBES8 .0015	.35 LBEV8	.014
.225 LBES2	1.6 LAES1	14 LADR8	72 LBCU6	15 LBEU3	2 7/8 LADV5	.045 LBES7 .0018	.4 LAES6	.016
.25 LBES3	1.75 LBDR8	16 LACR1	60 LBCU3	14 LBEV8	2 3/4 LADV4	.05 LBES6 .002	.45 LBEV4	.018
.3 LBES6	1.8 LAES2	18 LACR2	56 LBCV8	13 1/2 LBEU2	2 1/2 LADV3	.055 LBES4 .0022	.5 LBEV3	.02
.35 LBES8	2 LBCR1	20 LACR3	54 LBCU2	13 LBEV7	2 1/4 LADV2	.06 LBES3 .0024	.55 LBEV2	.022
.4 LBDS1	2.5 LBCR3	22 LACR4	48 LBCV6	12 LBEV6	2 LADV1	.065 LBES2 .0026	.6 LAES1	.024
.45 LBDS2	3 LBCR6	24 LACR6	44 LBCV4	11 1/2 LBEV5	1 3/4 LAEV8	.07 LBCU6 .0028	.65 LBCR2	.026
.5 LBDS3	3.5 LBCR8	26 LACR7	40 LBCV3	11 LBEV4	1 3/8 LAEV7	.075 LBES1 .003	.7 LACV8	.028
.6 LBDS6	4 LAER1	28 LACR8	36 LBCV2	10 LBEV3	1 1/2 LAEV6	.08 LBCU3 .0032	.75 LBCR1	.03
.7 LBDS8	4.5 LAER2	32 HADR1	32 LBCV1	9 LBEV2	1 1/4 LAEV4	.09 LBCV8 .0035	.8 LADU6	.032
.75 LBER6	5 LAER3	36 HADR2	30 LBDU3	8 LBEV1	1 1/4 LAEV3	.1 LBDS6 .004	.9 LACV4	.036
.8 LBCS1	5.5 LAER4	40 HADR3	28 LBDV8	7 1/2 LACU3	1 1/8 LAEV2	.11 LBCV5 .0045	1 LACV3	.04
.9 LBCS2	6 LAER6	44 HADR4	27 LBDU2	7 LACV8	1 LAEV1	.12 LBDS3 .0048	1.5 LAER1	.06
1 LBCS3	6.5 LAER7	48 HADR6	26 LBDV7	6 LACV6	7/8 HADV8	.125 LBCV3 .005	2 LADV3	.08
1.1 LBCS4	7 LAER8	56 HADR8	24 LBDV6	5 LACV3	3/4 HADV6	.15 LBDS1 .006	2.5 LADV1	.1
1.15 LBCS5	8 LADR1	64 HACR1	23 LBDV5	4 1/2 LACV2	5/8 HADV3	.175 LBDV8 .007	3 LADR1	.12
1.2 LBCS6	9 LADR2	72 HACR2	22 LBDV4	4 LACV1	1/2 HADV1	.2 LBCS6 .008	3.5 LAEV5	.14
1.25 LBDR3	10 LADR3	80 HACR3	20 LBDV3	3 3/4 LADU3	3/8 HAEV6	.225 LBDV4 .009	4 LAEV3	.16
1.3 LBCS7	11 LADR4	88 HACR4	19 LBDW1	3 1/2 LADV8	5/16 HAEV3	.25 LBDV3 .01	4.5 HADU6	.18
1.4 LBCS8	12 LADR6	112 HACR8	18 LBDV2	3 1/4 LADV7	1/4 HAEV1	.3 LBCS1 .012	5 LAEV1	.2
								
.05 LBES1	.9 LADS2	8 HADR1	240 LBCU3	19 HBDW8	4 1/2 LAEV2	.015 LBES8 .0006	.225 LBEV1	.009
.075 LBES6	1 LADS3	9 HADR2	160 LBCV3	18 LACV2	4 LAEV1	.02 LBES4 .0008	.25 LADS8	.01
.1 LBDS1	1.2 LADS6	10 HADR3	120 LBDU3	16 LACV1	3 3/4 HADU3	.025 LBCU6 .001	.3 LADS5	.012
.125 LBDS3	1.25 LAER3	11 HADR4	80 LBDV3	15 LADU3	3 1/2 HADV8	.03 LBCU3 .0012	.35 LADS3	.014
.15 LBDS6	1.5 LAER6	12 HADR6	60 LBEU3	14 LADV8	3 HADV6	.035 LBCV7 .0014	.4 LADU6	.016
.175 LBDS8	1.75 LAER8	13 HADR7	56 LBEV8	13 1/2 LADU2	2 3/4 HADV4	.04 LBCV5 .0016	.45 LACV1	.018
.2 LBCS1	2 LADR1	14 HADR8	44 LBEV4	13 LADV7	2 1/2 HADV3	.045 LBER6 .0018	.5 LACS8	.02
.225 LBCS2	2.25 LADR2	16 HACR1	40 LBEV3	12 LADV6	2 1/4 HADV2	.05 LBDU6 .002	.55 LAER1	.022
.25 LBCS3	2.5 LADR3	18 HACR2	36 LBEV2	11 1/2 LADV5	2 HADV1	.055 LBDU4 .0022	.6 LACS5	.024
.3 LBCS6	2.75 LADR4	20 HACR3	33 LACU4	11 LADV4	1 3/4 HAEV8	.06 LBER2 .0024	.7 LAEU8	.028
.35 LBCS8	3 LADR6	22 HACR4	32 LBEV1	10 1/2 LAEU8	1 1/2 HAEV6	.065 LBDV8 .0026	.75 LADR5	.03
.4 LAES1	3.25 LADR7	23 HACR5	30 LACU3	10 LADV3	1 3/8 HAEV4	.07 LBDV7 .0028	.8 LAEU6	.032
.45 LAES2	3.5 LADR8	24 HACR6	28 LACV8	9 LADV2	1 1/4 HAEV3	.075 LBCS5 .003	.9 LADV1	.036
.5 LAES3	4 LACR1	26 HACR7	27 LACU2	8 LADV1	1 3/8 HAEV2	.08 LBDV5 .0032	1 HADS8	.04
.6 LAES6	4.5 LACR2	28 HACR8	26 LACV7	7 1/2 LAEU3	1 HAEV1	.09 LBDR6 .0036	1.25 HADS4	.05
.625 LBCR3	5 LACR3		24 LACV6	7 LAEV8		.1 LBEU6 .004	1.5 LACR5	.06
.7 LAES8	5.5 LACR4		23 LACV5	6 1/2 LAEV7		.12 LBDR2 .005	2 HACS8	.08
.75 LBCR6	6 LACR6		22 LACV4	6 LAEV6		.15 LAES5 .006	2.5 HADR8	.1
.8 LADS1	6.5 LACR7		21 LADU8	5 1/2 LAEV4		.18 LBCR6 .007	3 HADR5	.12
.875 LBCR8	7 LACR8		20 LACV3	5 LAEV3		.2 LACU6 .008	4 HAEU3	.16

OPERATION

CARRIAGE AND APRON

A solid topslide is fitted as standard to the cross-slide, carried on a rotatable base, the cross-slide is made 60-0-60degree for accurate indexing. Carriage moves along the bed by hand or by power feed and supports the cross slide, compound rest, toolpost and cutting tools. The cross slide handle (1) and toolpost slide handle (2) move the cross slide and toolpost slide in and out.

Handwheel dials are graduated in inch or metric division to suit the operating screw and nut fitted.

The apron, anchored to front of carriage, contains the power longitudinal and cross feed controls. The engaging and disengaging of longitudinal and cross feeds is accomplished by lever (3) (drop worm system). lever (4) determines the engaging for the power longitudinal and cross feed. pull it out is for cross feed, and push it in is for longitudinal feed, and there is a neutral position for manual or thread cutting.


Pull and push the knob (5) on the front of the Apron, which can change the Threads and Feeds direction from the Apron.

The lever (6) is press downward to engage the leadscrew half-nut for thread-cutting.

The interlock device is equipped so that the longitudinal feed and the half-nut engaging can not work together. there are one safety device (auto stop) by means of slipping clutch which can be easily adjusted by screw (7 and 8).

The buttoms (9 and 10) on the front of carriage are for power rapid speed carriage moving. Before push the power rapid speed buttom push in the apron hand-wheel (11).

The buttom (12) on the front of carriage are for raip electrical brake, can stop the spindle rotation.




OPERATION

TAIL STOCK

Can be freed for movement along the bed by unlocking the clamp lever (A). The tailstock barrel is locked by lever (B).

The tailstock can be set-over for production of shallow tapers or for re-alignment. Release the clamping lever (A) and adjust screws (S) at each side of the base to move tailstock laterally across the base. Retightening and checking after adjustment of set over.

The tailstock is equipped with Dual spindle feed rate 1:1 and 1:1/4 which select by lever (C) for heavy drilling work by the tailstock.





MAINTENANCE

SLIDE WAYS ATTENTION

Tapered gib strips fitted to slideways of saddle cross-slide and top-slide (compound) so that any slackness which may develop can be rectified.

Ensure that slideways are thoroughly cleaned and lubricated before attempting adjustment. Then reset the gibs by slackening the rear gib screw and tightening the front screw, a little at a time. Check constantly for smooth action throughout full slide travel; avoid overadjustment which can result in increased wear-rate and stiff or jerky action.



CROSS-SLIDE NUT


This is adjustable for elimination of slackness which may develop in service. Reduce backlash by the cap-hand screw on the top of the cross-cover, then make only small adjustment by the cap-hand screw. Before operating the cross-slide several times by hand to be sure of smooth operation throughout travel.

MAINTENANCE

SPINDLE BEARING ADJUSTMENT

If spindle swing too freely or play is noticable when spindle is pushed back and forth or when the bearings are in the case of bearings noise or chattering or over temperature.

Properly practic adjust middle and front bearing or tightening the adjusting nuts in the headstock.




ADJUSTMENT OF OVERLOAD PROTECTION DEVICE

Apron has an overload protection device by means of slipping clutch.

This adjustment can be accomplished by adjusting screw (1) and (2).

Be sure do not adjust this screw so frequently because slipping clutch dose not wear so much even for a long period of use.



MAINTENANCE


LATHE ALIGNMENT (Part 1)

With the lathe installed and running. We recommend a check on machine alignment before commencing work. Check levelling and machine alignment at regular periods to ensure continued lathe accuracy.

A. Headstock check

Take a light cut with a keen tool over a 8in. (200mm.) length of 2 in. dia. (50mm.) steel bar gripped in the chuck but not supported at the free end. Micrometer readings at each end of the turned length (at A and B) should be the same.

To correct a difference in readings, slacken the six headstock hole-down screws (S) and adjust the screw (J) rear side of the headstock, to adjusting the headstock center. Tighten all screw after adjustment and repeat the test-cut/micrometer-reading, sequence until micrometer readings are identical, so machine now cutting absolutely parallel.




LATHE ALIGNMENT (Part 2)

B. Tailstock check

Using a 12 in. (305mm.) ground steel bar fitted between headstock and tailstock centers, check the alignment by fitting a dial-test indicator to the topslide and traversing the center line of the bar.

To correct error release the tailstock clamp lever and adjust the two set-over screws provided continue with checking and correction until the alignment is perfect.



INDEX


(1) ASEMBLY

HEADSTOCK -----	2
GEARBOX -----	9
ARRON -----	14
SADDLE -----	20
CROSS-SLIDE -----	21
TOP SKIDE -----	22
TAILSTOCK -----	23
BED,SHAFT -----	26
CABINET & PANELS -----	27
SWING FRAME & END GEARS -----	29
THREADING DAILS -----	30


(3) PARTS NUMBER - NAME REFERNECE

641001-641806 -----	15
642001-642273 -----	16
643101-643294 -----	17
644001-644096 -----	18
645011-645099 -----	19
646011-646097 -----	20
647001-647127 -----	16
648011-648751 -----	17
649015-649180 -----	18


ASSEMBLY HEADSTOCK(Casting Controls)




ASSEMBLY HEADSTOCK(Controls)




ASSEMBLY HEADSTOCK(Controls)




ASSEMBLY HEADSTOCK(Gears & Shaft)




ASSEMBLY HEADSTOCK(Spindle & Gears)




ASSEMBLY HEADSTOCK(Gears & Shaft)




ASSEMBLY GEARBOX(Casting & Controls)




ASSEMBLY GEARBOX(Controls)




ASSEMBLY GEARBOX(Gears & Shaft)




ASSEMBLY GEARBOX(Gears & Shaft)




ASSEMBLY GEARBOX(Gears & Shaft)




ASSEMBLY APRON(Casting)




ASSEMBLY APRON(Gears & Shaft)




ASSEMBLY APRON(Gear & Shaft)




ASSEMBLY APRON(Gears & Shaft)




ASSEMBLY APRON(Gears & Shaft)




ASSEMBLY APRON(Gears & Shaft)




ASSEMBLY SADDLE




ASSEMBLY CROSS-SLIDE




ASSEMBLY TOP-SLIDE




ASSEMBLY TAILSTOCK




ASSEMBLY TAILSTOCK




ASSEMBLY TAILSTOCK




ASSEMBLY BED, SHAFT




ASSEMBLY CABINET & PANELS



ASSEMBLY CABINET & PANELS




ASSEMBLY SWING FRAME & END GEARS



ASSEMBLY THREADING DAILS








ENGLISH (LEADSCREW 2 TPI)



STATIC ACCURACY TEST

swing 500 and over and under 1000






CNS

TYPE:		MACHINE SERIAL NO.		
NO.	SUBJECT OF MEASUREMENT	ILLUSTRATION	PERMISSIBLE ERROR	MEASURED ERROR
1.	Levelling of machine	(a) in longitudinal direction	 <p>(convex)</p>	± 0.05 mm/m
		(b) in transverse direction		± 0.05 mm/m
2.	Taper of spindle runs true	<p style="text-align: center;">300 mm long</p> 	Position A : 0.02 mm Position B : 0.03 mm	
3.	Spindle parallel with traverse of carriage	(a) in vertical plane		(a) 0.02/300 mm
		(b) in horizontal plane		(b) 0.02/300 mm
4.	Upper Slide (Parallelism of the Slide Longitudinal Movement to the Spindle Axis)		0.02/150 mm	
5.	Axis of centres parallel with bed in vertical plane		0.03/300 mm	

STATIC ACCURACY TEST

swing 500 and over and under 1000

CNS

6.	Tailstock spindle parallel with carriage guides (carriage traverse)	(a) in vertical plane		(a) 0.03/ 150 mm	
	(b) in horizontal plane	(b) 0.015/ 150 mm			
7.	Centring register of spindle runs true		0.02 mm		
8.	Spindle for axial float and true running of face of spindle flange		0.02 mm		
9.	Centre runs true		0.02 mm		
10.	Working accuracy of lathe on cylindrical turning		0.02mm (cylindricity) (D=25mm ~50mm)		
CHIEF ENGINEER :			INSPECTING ENGINEER :		