


JET L-95 SERIES CHAIN HOIST



JET L-95 SERIES CHAIN HOIST

REF	DESCRIPTION	1/2T	1T	1-1/2T
	PRODUCT #	101406	101416	101426
1	TOP HOOK	PELC0501	PELC1001	PELC1501
3	SAFETY LATCH	PEL90-016AA	PEL90-016BA	PEL90-016CA
17	BOTTOM HOOK	PELC05015	PELC10015	PELC15015
26	CHAIN STOP BOLT ASSY	PEL90-604A	PEL90-604B	PEL90-604CE
30	TOP HOOK PIN	PELC050105	PELC100105	PELC150105
31	GEAR SIDE PLATE ASSY	PELH0502	PELH1002	PELH1502
32	LOAD BEARING	PELH050411	PELH100411	PELH150411
35	WHEEL SIDE PLATE ASSY	PELH0503	PELH1003	PELH1503
36	LOAD BEARING	PELH050411	PELH100411	PELH150411
38	CVR NUT (GEAR&WHEEL)	PELC050205	PELC050205	PELC050205
39	SPRING WASHER	PELC050206	PELC050206	PELC050206
43	PAWL	PELC050510	PELC050510	PELC050510
45	E-RING	PELC050514	PELC050514	PELC050514
46	PAWL SPRING	PELC050512	PELC050512	PELC050512
47	ANCHOR PLATE PIN	PELC050221	PELC100221	PELC150221
48	ANCHOR PLATE	PELC050225	PELC100225	PELC150225
49	STAY PIPE	PELH050216	PELH100216	PELH150216
50	CHAIN STOP PIN SET	PELC050226	PELC100226	PELC150226
52	GEAR CASE ASSY	PELC05023	PELC10023	PELC15023
56	PINION SHAFT	PELH050301	PELH100301	PELH150301
57	CASTLE NUT	PELC050308	PELC050308	PELC050308
58	CASTLE NUT PIN	PELC050312	PELC050312	PELC050312
59	CHECK WASHER	PELC050508	PELC050508	PELC050508
60	PINION SHAFT WASHER	PELC050302	PELC100302	PELC150302
61	2ND & 3RD GEAR ASSY	PELC05024	PELC10024	PELC15024
64	LOAD GEAR	PELC050305	PELC100305	PELC150305
65	LOAD SHEAVE	PELH0507	PELH1007	PELH1507
68	LOAD SHEAVE COVER	PELC050405	PELC100405	PELC150405
69	LOAD SHEAVE COVER PIN	PELC050433	PELC100433	PELC150433
70	STRIPPER ASSY	PELC05027	PELC10027	PELC15027
73	HAND WHEEL COVER	PELC050218	PELC100218	PELC150218
75	DISC HUB	PELH05075	PELH10075	PELH15075
76	RATCHET GEAR	PELC050506	PELC100506	PELC150506
77	FRICTION DISC	PELC050507	PELC100507	PELC150507
78	BRAKE COVER	PELC050513	PELC100513	PELC150513
79	LOAD CHAIN	105205	105210	105215
80	HAND CHAIN	105255	105255	105255
81	NAME PLATE	PELH05081	PELH10081	PELH15081
86	TRANSMITTER	PELH05086	PELH10086	PELH15086
87	FRICTION PAD "B"	PELH05087	PELH10087	PELH15087
88	FRICTION PAD "A"	PELH05088	PELH10088	PELH15088
89	HAND WHEEL	PELH05089	PELH10089	PELH15089
90	WHEEL CATCHER	PELH05090	PELH05090	PELH05090
91	COIL SPRING	PELH05091	PELH05091	PELH05091
92	PRESSER	PELH05092	PELH10092	PELH15092
93	CONED DISC SPRING	PELH05093	PELH10093	PELH15093
94	NUT HOLDER PLATE	PELH05094	PELH10094	PELH15094
95	ADJUSTING NUT	PELH05095	PELH10095	PELH15095

JET L-95 SERIES CHAIN HOIST

REF	DESCRIPTION PRODUCT #	2T 101436	3T 101456	5T 101466
1	TOP HOOK	PELC2001	PELC3001	PELC5001
3	SAFETY LATCH	PEL90-016DA	PEL90-016EA	PEL90-016FA
17	BOTTOM HOOK	PELC20015	PELC30015	PELC50015
26	CHAIN STOP BOLT ASSY	PEL90-604D	PEL90-604CE	PEL90-604F
30	TOP HOOK PIN	PELC200105	PELC300105	PELC500105
31	GEAR SIDE PLATE ASSY	PELH2002	PELH1502	PELH5002
32	LOAD BEARING	PELH200411	PELH150411	PELH500411
35	WHEEL SIDE PLATE ASSY	PELH2003	PELH1503	PELH5003
36	LOAD BEARING	PELH200411	PELH150411	PELH500411
38	CVR NUT (GEAR&WHEEL)	PELC200205	PELC050205	PELC200205
39	SPRING WASHER	PELC200206	PELC050206	PELC200206
43	PAWL	PELC200510	PELC050510	PELC200510
45	E-RING	PELC200514	PELC050514	PELC200514
46	PAWL SPRING	PELC200512	PELC050512	PELC200512
47	ANCHOR PLATE PIN	PELC200221	PELC150221	PELC500221
48	ANCHOR PLATE	PELC200225	PELC150225	PELC500225
49	STAY PIPE	PELH200216	PELH150216	PELH500216
50	CHAIN STOP PIN SET	PELC200226	PELC150226	PELC500226
52	GEAR CASE ASSY	PELC20023	PELC15023	PELC50023
56	PINION SHAFT	PELH200301	PELH150301	PELH500301
57	CASTLE NUT	PELC050308	PELC050308	PELC050308
58	CASTLE NUT PIN	PELC050312	PELC050312	PELC050312
59	CHECK WASHER	PELC050508	PELC050508	PELC050508
60	PINION SHAFT WASHER	PELC200302	PELC150302	PELC500302
61	2ND & 3RD GEAR ASSY	PELC20024	PELC15024	PELC50024
64	LOAD GEAR	PELC200305	PELC150305	PELC500305
65	LOAD SHEAVE	PELH2007	PELH1507	PELH5007
68	LOAD SHEAVE COVER	PELC200405	PELC150405	PELC500405
69	LOAD SHEAVE COVER PIN	PELC200433	PELC150433	PELC500433
70	STRIPPER ASSY	PELC20027	PELC15027	PELC50027
73	HAND WHEEL COVER	PELC200218	PELC150218	PELC500218
75	DISC HUB	PELH20075	PELH15075	PELH20075
76	RATCHET GEAR	PELC200506	PELC150506	PELC200506
77	FRICITION DISC	PELC200507	PELC150507	PELC200507
78	BRAKE COVER	PELC200513	PELC150513	PELC500513
79	LOAD CHAIN	105220	105215	105225
80	HAND CHAIN	105255	105255	105255
81	NAME PLATE	PELH20081	PELH30081	PELH50081
86	TRANSMITTER	PELH20086	PELH15086	PELH50086
87	FRICITION PAD "B"	PELH20087	PELH15087	PELH50087
88	FRICITION PAD "A"	PELH20088	PELH15088	PELH50088
89	HAND WHEEL	PELH20089	PELH15089	PELH50089
90	WHEEL CATCHER	PELH05090	PELH05090	PELH05090
91	COIL SPRING	PELH05091	PELH05091	PELH05091
92	PRESSER	PELH20092	PELH15092	PELH50092
93	CONED DISC SPRING	PELH20093	PELH15093	PELH50093
94	NUT HOLDER PLATE	PELH20094	PELH15094	PELH50094
95	ADJUSTING NUT	PELH20095	PELH15095	PELH50095