


CoroDrill® 801

Inch version



DC	Included parts				Spare parts									
	1a	1b	2a	2b	3	4	5a	5b	6a	7	8			
	Central cartridge	Central cartridge	Intermediate cartridge	Intermediate cartridge	Peripheral cartridge	Insert screw	Screw	Screw	Screw	Insert screw	Screw			
67	L801-12T3C		R801-12T3I		R801-13T3P	5513 020-34	5513 020-26		5513 020-26	5513 020-24	3212 010-310			
70	L801-06T3C	L801-06T3C-2	R801-08T3I		R801-13T3P	5513 020-34	5513 020-25	5513 020-26	5513 020-25	5513 020-24	3212 010-310			
73-75	L801-12T3C		R801-12T3I		R801-1806P	5513 020-34	5513 020-26		5513 020-26	5513 020-25	3212 010-361			
76	L801-12T3C		R801-12T3I		R801-1806P	5513 020-34	5513 020-26		5513 020-26	5513 020-25	3212 010-361			
81-83	L801-06T3C	L801-06T3C-2	R801-12T3I		R801-1806P	5513 020-34	5513 020-25	5513 020-26	5513 020-26	5513 020-25	3212 010-361			
89	L801-06T3C	L801-08T3C	R801-12T3I		R801-1806P	5513 020-34	5513 020-25	5513 020-25	5513 020-26	5513 020-25	3212 010-361			
102-108	L801-12T3C		R801-12T3I	R801-12T3I	R801-1806P	5513 020-34	5513 020-26		5513 020-25	5513 020-25	3212 010-361			
111-114	L801-12T3C		R801-12T3I		R801-1806P	5513 020-34	5513 020-26		5513 020-25	5513 020-25	3212 010-361			
137-152	L801-12T3C		R801-08T3I	R801-12T3I	R801-1806P	5513 020-34	5513 020-26		5513 020-25	5513 020-25	3212 010-361			
165	L801-12T3C		R801-12T3I		R801-1806P	5513 020-34	5513 020-26		5513 020-25	5513 020-25	3212 010-361			
	Spare parts		Included parts		Spare parts		Included parts		Spare parts		Included parts			
	9	10	11	12	13	14	15	16	17a	17b	18a	19	20	21
DC	Washer	Screw	Cartridge shim set	Support pad shim set	Safety pad	Screw	Pad shim set	Screwdriver	Key	Key	Key	Screwdriver	Key	Screwdriver
67	3411 011-053	3214 010-357	5549 128-40	5549 126-90	801-142067-S	5513 020-01	5549 127-20	5680 046-01	5680 048-03		5680 048-03	5680 046-04	3021 010-040	5680 046-02
70	3411 011-053	3214 010-357	5549 128-40	5549 126-90	801-142067-S	5513 020-01	5549 127-20	5680 046-01	5680 048-01	5680 048-03	5680 048-03	5680 046-04	3021 010-040	5680 046-02
73-75	3411 011-064	3214 010-357	5549 128-40	5549 126-90	801-142067-S	5513 020-01	5549 127-20	5680 046-01	5680 048-03		5680 048-03	5680 046-02	3021 010-050	5680 046-02
76	3411 011-064	3214 010-357	5549 128-40	5549 126-90	801-142067-S	5513 020-01	5549 127-20	5680 046-01	5680 048-03		5680 048-03	5680 046-02	3021 010-050	5680 046-02
81-83	3411 011-064	3214 010-357	5549 128-40	5549 126-90	801-142067-S	5513 020-01	5549 127-20	5680 046-01	5680 048-01	5680 048-03	5680 046-02	5680 046-02	3021 010-050	5680 046-02
89	3411 011-064	3214 010-357	5549 128-40	5549 126-90	801-142067-S	5513 020-01	5549 127-20	5680 046-01	5680 048-01	5680 048-03	5680 046-02	5680 046-02	3021 010-050	5680 046-02
102-108	3411 011-064	3214 010-357	5549 128-40	5549 126-91	801-202582-S	5513 020-26	5549 126-10	5680 046-01	5680 048-03	5680 048-01	5680 046-02	5680 046-02	3021 010-050	5680 046-06
111-114	3411 011-064	3214 010-357	5549 128-40	5549 126-91	801-202582-S	5513 020-26	5549 126-10	5680 046-01	5680 048-03	5680 048-01	5680 046-02	5680 046-02	3021 010-050	5680 046-06
137-152	3411 011-064	3214 010-357	5549 128-40	5549 126-91	801-202582-S	5513 020-26	5549 126-10	5680 046-01	5680 048-03	5680 048-01	5680 046-02	5680 046-02	3021 010-050	5680 046-06
165	3411 011-064	3214 010-357	5549 128-40	5549 126-91	801-202582-S	5513 020-26	5549 126-10	5680 046-01	5680 048-03	5680 048-01	5680 046-02	5680 046-02	3021 010-050	5680 046-06

Keys (mm/Torx Plus) sizes, see page 147

