Quick Links

Resource Library Safety Data Sheets (SDS) Video Library

Some of these links lead to web-based resources that are not product-specific.



Product Description

The 3M™ ScotchBrite™ Power Pad 2000 is an all-purpose hand pad which scours faster but scratches less than many conventional scouring products. This pad is made from high quality fibers, scouring particles, and resin.

Special Features:

- Unique bow-tie shape for ease of handling.
- Scours 2-4 times faster than conventional commercial scouring pads, and is 6-10 times less abrasive than other conventional commercial scouring pads.
- **Fiber:** Durable synthetic fibers that are crimped and heat set to create strong web.
- Scouring Particles: Unique soil-removing particles for effective scouring, cleaning, and scrubbing. Particles are evenly distributed throughout the pad to ensure effective, consistent scouring, and lasting performance throughout the life of the pad.
- Resin: High quality bonding resin system designed to provide resistance to degradation from exposure to hot water, detergents and normal cleaning liquids.

Applications

Test in an inconspicuous area prior to use.

Use for cleaning a wide variety of surfaces. Ideal for cleaning surfaces where minimal scratching is desired.

Kitchen: Stainless steel surfaces and appliances, heavily baked-on food soil on pots and pans, cooking appliances, coolers, ceramic tile, countertops, and maintenance equipment.

Bathrooms: Sinks, faucets, porcelain and ceramic.

General: Elevator doors, doors, kick plates, desktops, floors, walls, drinking fountains, lockers, ceramic tile, and glass.

Packaging

2000: 20 Pads/Case

2000BP: 20 Pads/Box, 3 Boxes/Case

General Use Directions

The pad can be used wet or dry.

- 1. Hold pad with one hand.
- 2. Place either side of the pad against the surface to be cleaned, apply desired pressure and scrub the area in circular motion.
- 3. Rinse off scrubbed areas with clean water or wipe off with clean, damp cloth.
- 4. Clean pad as necessary after use.

Pad Cleaning Instructions

Cleaning pad provides multiple uses. Used and/or worn-out pads can be disposed of in regular kitchen trash.

Pads can be rinsed with warm or hot water or soaked in a cleaning solution to dissolve caked-on soil and grease.

Pad Cleaning by Hand

- 1. Spray or rinse off excess food debris from pad using a dish sprayer or sink faucet.
- Wash the pad in soapy water to remove any remaining food debris and grease. Remove embedded food debris from pad by hand.
- Rinse pad with clean water. Make sure no food debris is left on the pad. Squeeze excess water from the pad and allow to air dry.

If desired, soak pad in sanitizer solution. After soaking, squeeze excess solution from the pad, rinse and allow to air dry.

Pad Cleaning by Dishwasher

- Spray off or rinse excess food debris from pad using dish sprayer or sink faucet. Remove stubborn food debris such as cheese from pad by hand.
- 2. Place pad in dishwasher and make sure both sides of the pad are exposed to washing.
- 3. After washing, take pad out of dishwasher and allow to air dry.



3M™ ScotchBrite™ Power Pad 2000 and 2000BP

Product Specifications

(Typical Values)

1. Size:

Pad Length: 5.5 inches Pad Width: 3.9 inches Pad Thickness: 0.40 inches

2. **Color:** Dark Blue

3. **Shape:** Bow-tie

Precautionary Summary

For other soft surfaces or easily scratch surfaces, test in an inconspicuous area using light pressure before use on these surfaces.

Health and Safety

When handling any chemical products, read the manufacturers' container labels and the Safety Data Sheets (SDS) for important health, safety and environmental information. To obtain SDS sheets for 3M products go to 3M.com/SDS, or by mail or in case of an emergency, call 1-888-364-3577 or 1-651-737-6501. When using any equipment, always follow the manufacturers' instructions for safe operation.

Technical Information

Technical information and data, recommendations, and other statements provided by 3M are based on information, tests, or experience which 3M believes to be reliable, but the accuracy or completeness of such information is not guaranteed. Such technical information and data are intended for persons with knowledge and technical skills sufficient to assess and apply their own informed judgment to the information. The typical values shown should not be used for the purpose of specification limits. If you have questions about this Product, contact the **Customer Service Department at 1-800-852-9722.**

Product Use

Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty

3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Limited Remedy

If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

No Extension of Warranty

In the case of an approved warranty claim, the replacement Product will carry only the remaining term of the original warranty period.

Limitation of Liability

Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.

